



For presentation only

PLASTCRETE MIX DESIGN

Below is a technique of repair of damaged, contaminated, or aged concrete by thin layers.

1. Spray Kalmatron® KF-G (300 Gram/1 Liter of water) by 2 Liters/m² on area of application.
2. Apply PLASTCRETE no sooner than after 45 minutes.
3. Spray Kalmatron® KF-G before trowelling when shiny concrete surface is needed.
4. Curing is not required.

Material	UNITS OF MEASUREMENTS				NOTICE: proposed mix is designed for application of the layers with minimal thickness at 2 mm.
	Lbs	CF	Kg	m ³	
Ordinary Portland Cement	700	3.555	400	0.126	
Coarse Sand #16	2640	18.839	1670	0.7157	
Krete ¹⁰⁰	17	.17	10	0.0062	
Water	266	4.436	152	0.1521	W/C = 0.38
Total	3,623	27	2232	1.00	D = 2300 Kg/m ³ or 135 LB/CF

PLASTCRETE BATCH INSTALLATION

1. Batch must be no smaller than 150 Kg.
2. Turn on mixer for 3 minutes.
3. In a case of the batch stiffness do not add water. Continue mixing another 2 minutes.
4. Continue mixing during of application. Do not stop mixer.
5. Vibrate until coarse aggregate appears on a surface.

ESSENTIALS AND CURING

1. After application, do not provide curing procedure and do not use curing compounds.
2. Do not cover fresh PLASTCRETE with any films or blankets.
3. Expected results: - Compressive Strength at 55 MPa
- Tensile Strength at 11 MPa
- Water impermeability is > W12

KALMATRON® CORPORATION

- This information is an intellectual property of the KALMATRON® Corporation and any attachments are confidential, may contain privileged sources and are protected by the contents of the patents, trademarks, and copyrights laws.
- You notified that any publicity, distribution, dissemination, reformatting, or copying is prohibited and will be prosecuted under the Laws of USA Patent & Trademark Office.
- When decision to use presented information for industrial application will come, do not hesitate to obtain proprietary rights to own it for your benefits with our technical support. Thank you.